



FIG. 1








FIG. 4






FIG. 5



6 / 1 4

FIG. 6(a)



MENU  
VIDEO TUNING  
ENERGY-SAVING SETTING  
MAIN UNIT SETTING  
CHANNEL SETTING  
TIMER SETTING





 : SELECT  
 : ENTER  
 : END

FIG. 6(a)



CHANNEL SETTING  
RETURN  
AUTO PRESET [— —]  
MANUAL MEMORY [— —]  
AREA NUMBER [— —]  
EXECUTION








 : SELECT  
 : ENTER  
 : END

FIG. 6(c)



CHANNEL SETTING  
RETURN  
AUTO PRESET [YES]  
MANUAL MEMORY [— —]  
AREA NUMBER [— —]  
EXECUTION

 : SELECT  
 : ENTER  
 : END

7 / 1 4

FIG. 7(a)

CHANNEL SETTING  
 RETURN  
 AUTO PRESET [YES]  
 MANUAL MEMORY [— —]  
 AREA NUMBER [— —]  
 EXECUTION

FIG. 7(a)

AUTO PRESET 10

"CHANNEL NUMBERS FROM 1 TO 62  
 WILL BE DISPLAYED IN NUMERIC ORDER"


FIG. 7(c)

213

1	14	3
4	38	6
42	8	46
10	— —	12

8 / 1 4


FIG. 8






9 / 1 4

FIG. 9




10/14

FIG. 10




1 1 / 1 4

FIG. 11




1 2 / 1 4

FIG. 12



1 3 / 1 4

FIG. 13



1 4 / 1 4

FIG. 14(a)




FIG. 14(b)




FIG. 14(c)

